Click to prove you're human

Share — copy and redistribute the material in any medium or format for any purpose, even commercially. Adapt — remix, transform, and build upon the material for any purpose, even commercially. The licensor cannot revoke these freedoms as long as you follow the license terms. Attribution — You must give appropriate credit , provide a link to the license, and indicate if changes were made . You may do so in any reasonable manner, but not in any way that suggests the licensor endorses you or your use. ShareAlike — If you remix, transform, or build upon the material, you must distribute your contributions under the same license as the original. No additional restrictions — You may not apply legal terms or technological measures that legally restrict others from doing anything the license permits. You do not have to comply with the license for elements of the material in the public domain or where your use is permitted by an applicable exception or limitation . No warranties are given. The license may not give you all of the permissions necessary for your intended use. For example, other rights such as publicity, privacy, or moral rights may limit how you use the material. It’s incredibly frustrating when your Dyson vacuum, known for its powerful suction, suddenly stops working. You rely on it to keep your home clean, and a malfunctioning vacuum disrupts that. A Dyson vacuum not working can stem from a variety of issues, ranging from simple blockages to more complex motor problems. Don’t immediately assume the worst and rush to replace it! This article will walk you through a comprehensive troubleshooting guide to diagnose and fix the most common reasons why your Dyson vacuum isn’t working. We’ll cover everything from checking for clogs to resetting the machine, helping you get back to a spotless home. Let’s dive in and get your Dyson back in action.Quick Answer: A Dyson vacuum not working is often due to a blockage, full dustbin, or a tripped reset button. Check these first, then move on to filter cleaning and motor inspection.Takeaway:Check for blockages in the wand, hose, and brush head.Empty the dustbin and clean the filters regularly.Ensure the vacuum is properly assembled and the power cord is secure.1. The Most Common Culprit: BlockagesA blockage is the number one reason a Dyson vacuum loses suction or stops working altogether. These powerful machines can easily suck up larger debris, which can then get lodged in various parts of the system. Identifying and removing these blockages is often the quickest fix.Identifying Blockage LocationsStart by systematically checking these areas:Wand: Detach the wand and look through it for any visible obstructions. Use a long, flexible object (like a broom handle) to gently push through any blockages.Hose: Disconnect the hose and inspect it thoroughly. A flexible wire or coat hanger can be helpful for dislodging stubborn clogs.Brush Head: Remove the brush bar and check for tangled hair, string, or other debris wrapped around it. Many Dyson brush heads have a coin-operated release to easily remove the bar for cleaning.Cyclone Assembly: This is where larger debris can accumulate. Refer to your Dyson’s manual for instructions on how to safely disassemble and clean the cyclone.Remember to always unplug your Dyson before attempting to clear any blockages. A blocked vacuum can overheat and potentially cause damage.2. Emptying the Dustbin: A Simple SolutionIt seems obvious, but a full dustbin can significantly reduce suction power and even cause your Dyson to stop working. The vacuum relies on airflow to operate efficiently, and a packed dustbin restricts that flow.Emptying the dustbin is a quick and easy task. Most Dyson models have a simple “push-button” release mechanism. Ensure the dustbin is completely empty before reattaching it. Also, give the dustbin a quick rinse with water and allow it to dry completely before using it again. This prevents dust buildup and maintains optimal performance.3. Filter Maintenance: Keeping Airflow OptimalDyson vacuums utilize filters to capture fine dust particles and allergens. Over time, these filters become clogged, restricting airflow and reducing suction. Regular filter cleaning and replacement are crucial for maintaining your Dyson’s performance.Cleaning and Replacing FiltersWashable Filters: Most Dyson filters are washable. Remove the filters and rinse them under cold water until the water runs clear. Allow them to dry completely (at least 24 hours) before reinstalling.Filter Replacement: Filters have a limited lifespan. Check your Dyson’s manual for recommended replacement intervals. Using old or damaged filters can significantly impact performance.Filter Location: Filter locations vary depending on the Dyson model. Consult your manual to find the correct filters and cleaning instructions.A clean filter ensures optimal airflow and prevents your Dyson from overheating.4. Checking the Power Supply and ConnectionsBefore diving into more complex troubleshooting, ensure the issue isn’t simply related to the power supply. A loose connection or faulty power cord can prevent your Dyson from turning on.Power Cord: Inspect the power cord for any damage, such as cuts or fraying. If the cord is damaged, do not use the vacuum and consider professional repair.Outlet: Test the outlet with another appliance to ensure it’s working correctly.Connections: Make sure the power cord is securely plugged into both the vacuum and the outlet.Sometimes, the simplest solutions are the most effective.5. Resetting Your Dyson: A Quick Fix for OverloadDyson vacuums have a built-in thermal overload protection feature. If the motor overheats (often due to a blockage), the vacuum will automatically shut off. Resetting the vacuum can often resolve this issue.How to Reset Your DysonThe reset process varies slightly depending on the model, but generally involves these steps:Unplug the vacuum.Remove the battery (if applicable).Wait 30-60 minutes for the motor to cool down.Reinstall the battery (if applicable).Plug the vacuum back in and try turning it on.If the vacuum still doesn’t turn on after resetting, there may be a more serious issue.6. Inspecting the Motor: A More Complex IssueIf you’ve tried all the previous steps and your Dyson still isn’t working, the motor may be the problem. Motor issues are more complex and often require professional repair.Signs of a Motor ProblemBurning Smell: A burning smell indicates the motor is overheating or has a damaged component.No Power: The vacuum doesn’t turn on at all, even after resetting.Weak Suction: The suction is significantly weaker than usual, even after clearing blockages and cleaning filters.Unusual Noises: Loud grinding or whirring noises coming from the motor.Do not attempt to disassemble or repair the motor yourself. This can be dangerous and may void your warranty. Contact Dyson customer support or a qualified appliance repair technician. You can find more information on Dyson’s website: . Addressing Brush Bar IssuesSometimes, the issue isn’t with the suction, but with the brush bar itself. If the brush bar isn’t spinning, it won’t effectively agitate the carpet and pick up dirt.Common Brush Bar ProblemsTangled Hair: Excessive hair wrapped around the brush bar can prevent it from spinning. Regularly remove tangled hair and debris.Broken Belt: The brush bar is driven by a belt. If the belt is broken or stretched, the brush bar won’t spin. Replace the belt according to your Dyson’s manual.Motor Issue: In rare cases, the brush bar motor itself may be faulty. This requires professional repair.Before replacing any parts, ensure the brush bar is properly seated and that there are no obstructions preventing it from spinning. If you’re struggling with stubborn stains after cleaning, consider how to remove gravy stains from carpet: Common Dyson Vacuum ProblemsQ: Why does my Dyson keep shutting off? A: This is often due to overheating caused by a blockage or full dustbin. Reset the vacuum after clearing any obstructions and emptying the dustbin.Q: How often should I clean my Dyson filters? A: Washable filters should be cleaned every few weeks, depending on usage. Replace filters every 6-12 months, or as recommended in your Dyson’s manual.Q: My Dyson has suction, but it’s very weak. What could be the problem? A: Weak suction is usually caused by a blockage, full dustbin, or dirty filters. Check and address these issues first.Q: Can I use water to clean the entire Dyson vacuum? A: No. Only certain parts, like the dustbin and washable filters, can be washed with water. Avoid getting water on the motor or electrical components.Q: What do I do if my Dyson still isn’t working after trying these steps? A: Contact Dyson customer support or a qualified appliance repair technician for assistance.Conclusion: Keeping Your Dyson Running SmoothlyA Dyson vacuum not working can be a frustrating experience, but often the solution is simpler than you think. By systematically checking for blockages, emptying the dustbin, cleaning the filters, and ensuring a proper power supply, you can often resolve the issue yourself. Remember to prioritize safety and consult your Dyson’s manual for specific instructions. Regular maintenance is key to keeping your Dyson performing at its best. If you’re still facing issues, don’t hesitate to seek professional help. A well-maintained Dyson will continue to provide powerful cleaning for years to come. And if you’re looking for ways to maintain other surfaces in your home, you might find this article on cleaning hardwood floors helpful: . Imagine being in the zone, tidying up your home like a boss, and BAM! Your trusty vacuum takes a nap on you. Don't Miss Out! Click For Amazon's Exclusive Vacuum Deals! It’s a feeling that’s almost as bad as running out of snacks during a binge-watching session.And when it’s a top-brand like Dyson, it can feel like a real kick in the dust bunnies But don’t despair, my friend!If your Dyson vacuum stopped working, there are a number of things you can try to get it back up and running.In this post you will learn:Possible reasons why your Dyson vacuum cleaner no longer turns onTroubleshooting steps for each potential fixAnd more! You can use this guide to fix any Dyson vacuum model, so let’s get started If your Dyson vacuum stopped working, it might be due to a damaged power cord, a faulty switch, clogs in the hose, a jammed motor, and more. Clogs are the most common reason for Dyson vacuums not turning on. However, I recommend you follow each step below to inspect each Dyson vacuum component, and start with a test of the power outlet and breakers.The comprehensive step-by-step guide below has 10 fixes you can try.But if you prefer watching videos, you can go through this fantastic video by electronicsNmore.You won’t see a Dyson vacuum cleaner in the video, but the things to check are pretty much the same for all brands:Even if your Dyson vacuum cleaner no longer turns on, it might not be time to send your machine to vacuum heaven just yet!Take a deep breath and follow these handy troubleshooting tips below to get your Dyson back up and running again:The number one thing you’d want to try is to inspect the circuit breaker and ensure it has not tripped. If it has, flip it back.Once you have done that, test your Dyson vacuum cleaner to see if works.If the breaker has not tripped, try step 2.A malfunctioning power outlet may cause your Dyson vacuum cleaner to stop working.To determine if this is the issue, you can perform the following tests. Check if your Dyson turns on after running each of the individual tests below:Check how firmly your Dyson vacuum power cord is connected to the outlet by gently wiggling the cord. If the plug easily disconnects from the outlet, push the power plug back in to ensure it is securely and fully connected to the outletUnplug the cord and plug it in againTest the power outlet by plugging in another device such as your mobile phone. If your phone starts charging, then the power outlet is likely not the cause of the issue. However, if the phone does not start charging, then you might want to try and plug your Dyson vacuum into a different outlet to see if the current outlet is damagedNot all vacuums are powered by batteries, but for those that are, a dead battery could be the culprit of a Dyson that has stopped working.The easy step to finding out? Plug it in!If the battery is no longer able to charge, it’s time to consider a replacement.Just make sure to opt for an original Dyson battery to avoid nasty surprises.I always recommend to empty your Dyson dustbin after each use, or, at best, once it is no more than 3/4 full.If your Dyson vacuum cleaner has stopped working, chances are the dustbin is overflowing with debris and putting a strain on the motor.So, do yourself (and your vacuum) a favor, and make sure to always give the dustbin a good clear-out before it reaches maximum capacity. Trust me, your Dyson vacuum will thank you!To empty the dustbin:Turn off the vacuum and unplug it from the power sourceLocate the release button for the dustbin on the vacuum bodyPress the release button to detach the dustbin from the body of your DysonHold the dustbin over a trash can and press the bottom release catch to empty the contents into the trash canOnce the dustbin is empty, replace it back onto the vacuum body and make sure it is securely in placeNote: The exact process may vary depending on the model of your Dyson vacuum. Go to to find the user manual for your machine.A clogged hose can lead to a loss of suction or even cause your Dyson vacuum to stop working altogether.Here’s how to get that hose back in tip-top shape:Start by unplugging your Dyson for safetyDetach the hose from both the dustbin and any attachmentIdentify the blockage in the hose and use a long object to remove itIf the clog is difficult to get rid of, consider using pliers to get the job doneOnce the blockage has been removed, reassemble your Dyson vacuum cleaner and test it to see if it finally works againAh, the roller brush – the unsung hero of your Dyson vacuum.This little guy is like a personal dance instructor for your carpet, helping to loosen up dirt and debris as it twirls and twirls The brush is located under the vacuum head and can often become clogged with clumps of hair or other debris, which can lead your Dyson vacuum to stop working.To clean your Dyson vacuum roller brush, do the following:Locate the plate (underneath or on one side of the vacuum head) that allows to remove the brush rollerRemove the plateGet the brush roller out and use a pair of scissors to cut through hair that is wrapped around the brushRun the roller brush under warm water to remove any remaining dirt or debris.Important: Let the roller brush air dry for a minimum of 24 hours before installing it back in your Dyson vacuum cleaner.The filter is usually located near the top of the Dyson vacuum cleaner, near the dustbin.Some Dyson vacuums can have two filters: a pre-motor filter and a post-motor filter.In addition, some filters can be washable while others can only be replaced.Remove the filter and rinse it under running water, or machine wash them if the manufacturer allows itLet the filter dry naturally, preferably for 24 hours or until fully dryPut the filter back into your Dyson vacuum cleaner.If your Dyson vacuum filters cannot be washed, replace them periodically as per the manufacturer’s instructions to maintain your machine’s performance.Before you dive into inspecting your Dyson vacuum power cord, make sure to take the necessary safety precautions by unplugging it from the power source.Take a good look at the cord and check for any signs of damage like frayed wires or exposed insulation.If you spot any of these red flags, it’s best to leave the repair to a professional.However, if you’re feeling confident and up for a DIY challenge, here’s the step-by-step process to replace the cord:Unplug your Dyson vacuum cleanerDetach the old cord from the motor housing and other partsRoute the new cord through the same path and reattach it to the vacuumPlug the vacuum back in and give it a test run!Remember, if you choose to tackle the repair yourself, you take full responsibility for the outcome.Here is a video from FIX Tech Guides that shows how to do it:Your trusty Dyson vacuum cleaner has a little magic button that makes it all work – the switch!This tiny powerhouse is responsible for letting the electricity flow to the motor, and starting the suction cycle.But, if the switch is malfunctioning, your Dyson won’t be able to do its job effectively.To check if the switch works as it should, simply grab a trusty multimeter and test the continuity between the two terminals on the switch.If the multimeter indicates that there is continuity, then the switch is working correctlyIf there is no continuity, then the switch may need replacingIf your Dyson vacuum cleaner’s switch needs to be replaced, do the following:To start, disconnect the power cord from your DysonRemove the screws that hold the switch in place and carefully pull the switch out of its housingTo install the new switch, simply reverse these steps.If your Dyson vacuum has stopped working, it may be due to a jammed motor.This can occur if your Dyson is used for tasks it was not designed for, such as vacuuming metal shavings or plaster dust! Using your Dyson vacuum cleaner without the filter can also cause jams in the motor, since filters are designed to prevent debris from getting through to the motor.I don’t recommend you do this yourself, since it can be dangerous and void the warranty your machine came with.Call an expert instead.But if you do decide to go ahead, I am afraid I cannot take any responsibility for anything that may be going wrong!1. Unplug your Dyson vacuum cleaner and remove the housing. This will give you access to the motor2. Use a Phillips head screwdriver to remove the screws that hold the motor in place3. Carefully remove the motor from the housing and set it aside on a clean surface4. Use a flat head screwdriver to remove any dirt or debris that may be caught in the brushes of the motor. Be sure to clean both sides of the brushes thoroughly5. Once the brushes are clean, apply a few drops of Dyson vacuum cleaner oil to each one. This will help keep them working properly and extend their life span6. Reassemble your Dyson vacuum cleaner and test it outIf you’ve exhausted all troubleshooting options and your Dyson vacuum cleaner is still not working, it might be worth checking if it’s still covered under warranty.In this case, reaching out to the manufacturer for support could be your next step.They can provide additional advice, repair the machine, or even replace it if needed.If your efforts to fix your Dyson vacuum have been unsuccessful, and your machine is no longer under warranty, you may want to seek assistance from a professional.A technician can assess the problem and determine whether a repair can be made or if a replacement vacuum is needed.The technician should provide a cost estimate before proceeding with any repairs.At this point, you will probably find that replacing your Dyson vacuum might be the most cost effective option!With a little bit of troubleshooting, you can fix most Dyson vacuum cleaner problems yourself. To recap, if your Dyson vacuum stopped working, do the following:Check the circuit breaker has not trippedTest the power outlet your Dyson vacuum is plugged intoCheck that your Dyson vacuum battery is not flatEmpty the dustbinRemove clogs from the hoseClean the brush rollerWash or replace your Dyson vacuum filter/filtersInspect the power cord for visible damageTest your Dyson vacuum switchClean your Dyson vacuum motorIf your Dyson vacuum has definitely called it quits, it’s time to upgrade to a shiny new model.But don’t just buy the first vacuum that catches your eye – do your homework and make an informed decision.After all, you want a machine that’ll stick around for the long haul and not just suck up your money! As someone who tests Dyson vacuum cleaners for a living, I've always been impressed by its mighty suction power, innovative features and eye-catching design.And after owning a few Dyson vacs of my own, I’ve managed to pick up some clever hacks that make them even better along the way. From vacuuming more slowly to sticking to Eco mode, even the best vacuum cleaners need regular care and TLC.But what happens when your trusted Dyson suddenly stops working properly? Or if you’ve noticed that it doesn’t have as much suction power as it used to? You may like Luckily, it’s not the end of the world, and there are a number of possible reasons why your Dyson is letting you down.So before you rush out to replace your vacuum cleaner, check out these top reasons for your faulty Dyson vacuum cleaner — and how to keep it in top condition.The filters are clogged Dusty Dyson filter (Image credit: Future)Generally, vacuum cleaners only have one job to do — sucking up dirt, grime and stubborn hair. However, when you’ve lost suction power, and still see traces of dirt on your floors, that can defeat the entire purpose.Check first if the hose or filter might be clogged with a build-up of dirt. As your filter collects more dust, this limits the airflow, which in turn reduces the suction power.Get instant access to breaking news, the hottest reviews, great deals and helpful tips.If it is clogged up, you’ll need to either wash or remove the dirt with a brush (never wash HEPA filters with water), or replace with a new one.For more top tips, check out how to clean your Dyson's filter to ensure it maintains its powerful performance.The dust canister is full(Image credit: Future)Another reason why you might be losing suction power is if you have a full canister. Similarly, too much dirt and debris filling it to the brim can restrict the airflow and reduce suction power.The general rule of thumb is to always empty the canister before it gets to the half-way mark. Or better still, empty the canister after each use. This should improve the suction power and overall performance.The Brush bar isn't rotating(Image credit: Tom's Guide)If you've checked for dust build up and your filter is clean, but you still notice dirt and debris left behind on hard floors or carpets after a cleaning session, then you’ll need to check that your Dyson brush bar is actually rotating.If you find it has stopped when powered on, this means debris or stubborn hair has wrapped around the brush, preventing it from spinning. Luckily, this is an easy fix.Simply use scissors or a sharp tool to carefully pull away on tangled hair or debris on the brush bar to remove it. Or if you have a more problematic blockage, you can take the brush bar out of the housing for quick maintenance.The wand is blocked(Image credit: Future)There's a pattern here: all parts of your Dyson vacuum can get blocked over time, so you'll also want to check that your wand, crevice tool or other attachment isn’t clogged.Check both ends of the wand or tool and remove any visible blockages as necessary to get full suction. Look out for cracks and other damage too, as if those exist, you should order replacements to ensure you get efficient cleaning results each time.The battery is faulty(Image credit: Future)Dyson vacs are known for its exceptional battery life, with certain models offering up to 60 minutes runtime. However, if it's not lasting as long as it used to, you could have a faulty or damaged battery.Of course, this will all depend on the power mode that you’re using (Boost will run it down quicker), while sticking to the Eco setting may preserve battery life. However, if you suspect a faulty or broken battery, you just need to buy a replacement battery for your specific Dyson model.More from Tom's Guide If you’re like me and you rely on the internet for almost everything — work, entertainment,… If you’re experiencing a blinking blue light on your Spectrum router, don’t panic! I understand that… As a Spectrum subscriber, I really enjoyed the services and bundles they offer. From being able… Spectrum routers are powerful devices that allow us to connect to our home or office’s network.… Our modems are just like our bodies. Just like how a headache indicates we have a… Your modem immediately lets you know what’s wrong with it through the colors flashed on the… Has your Eero been malfunctioning lately, and you’ve been wondering how to reset Eero? Luckily, resetting… Your Eero devices always tell you their status through the LED lights on top. On a… Dyson vacuums have revolutionized the way we clean our homes, combining innovation with functionality. However, like any appliance, they can experience issues that render them less effective or completely non-operational. If you’re wondering, “Why is my Dyson vacuum not working?” you’re not alone. This comprehensive guide will help you troubleshoot common problems, understand potential reasons behind them, and offer actionable solutions to get your vacuum back in optimal working condition.Understanding the Common Issues with Dyson VacuumsDyson vacuums are renowned for their strong suction and advanced filtration systems, but several factors can lead to malfunction. Let’s explore some common problems that users encounter:Loss of SuctionPower IssuesBlockagesBrush Bar ProblemsBattery ProblemsEach issue has its own set of troubleshooting steps, so it’s crucial to identify what’s amiss with your particular model.Loss of SuctionOne of the most common complaints among Dyson vacuum users is a loss of suction power. This can dramatically affect cleaning efficiency and leave you frustrated. Here are some reasons why this might occur.Clogged FiltersFilters can become clogged over time, especially if you have pets or if you vacuum regularly. Clogged filters disrupt the airflow, leading to reduced suction.SolutionTo address this issue, perform the following steps:Turn off and unplug your Dyson vacuum.Remove the filter, usually found near the ball or on the side.Rinse the filter under cold water. Avoid using detergents or cleaners.Allow the filter to dry for a minimum of 24 hours before reinserting.Blocked Hoses and AttachmentsAnother common reason for a loss of suction could be blockages in the vacuum’s hose or attachments. Hair, dirt, and debris can accumulate and obstruct airflow.SolutionExamine the hose and attachments for visible blockages.Use a long object, like a broom handle, to gently dislodge any clogs.Disconnect each attachment and inspect for blockages, using the same method to clear them.Power IssuesIf your Dyson vacuum won’t turn on at all, it could be a power-related issue. Here are some common causes and their respective solutions.Unplugged or Faulty PlugIt may sound simple, but often the cause can be as straightforward as a plug that isn’t securely inserted into the outlet.SolutionCheck to ensure that the vacuum’s plug is firmly connected to a functioning power outlet.If using an extension cord, try plugging directly into the wall socket.Defective Power CordIf the vacuum still does not work, inspect the power cord for any visible damage. Bumps, tears, or breakages could prevent the vacuum from receiving power.SolutionExamine the entire length of the power cord for damage.If you notice any issues, it’s advisable to reach out to Dyson support for repair or replacement options.Blockages in Your Vacuum CleanerSometimes, the problem may not be with the power or filters, but rather with blockages elsewhere in the vacuum.Dirty Dirt BinA full or dirty dirt bin can affect performance by obstructing airflow and suction.SolutionEmpty the dirt bin regularly. Depending on the model, you should empty the bin once it reaches the fill line.Clean your dirt bin with warm, soapy water and allow it to dry completely before putting it back.Obstructions in the Brush BarLong hair or pet fur can get tangled in the brush bar, stopping the bristles from rotating properly.SolutionTurn off and unplug the vacuum.Inspect the brush bar for hair and debris.Use scissors to carefully cut away any tangles, ensuring that the bristles are free to rotate.Brush Bar ProblemsThe brush bar is one of the core functionalities of a Dyson vacuum, particularly for models designed for carpets. If it’s not functioning properly, cleaning effectiveness decreases significantly.Brush Bar Not SpinningIf the brush bar is not rotating, it may not effectively pick up dirt and debris from carpets and rugs.SolutionCheck the brush bar switch – ensure it is turned on.Ensure the vacuum is in the correct position for carpet cleaning; using it on a hard floor might prevent the brush from spinning.If the brush is locked due to hair or debris, follow the previous cleaning steps.Battery ProblemsCordless Dyson vacuums offer incredible versatility but can suffer from battery-related issues affecting their performance.Battery Not Holding ChargeOver time, batteries can lose their effectiveness, leading to shorter usage times.SolutionEnsure the vacuum is properly seated on the charger.Leaving it to charge for a full 3-5 hours can sometimes reset minor issues.If the battery doesn’t hold a charge after full charging, consider contacting Dyson for a replacement.Additional Troubleshooting StepsIf your Dyson vacuum still isn’t working after following the above recommendations, consider these additional troubleshooting steps.Rebooting the VacuumSome models are equipped with an integrated reset function.SolutionTurn off and unplug the vacuum.Wait for a minute before plugging it back in and turning it on.Checking for Software IssuesSome newer Dyson models have smart features that may need software updates.SolutionFor applicable models, check the manufacturer’s website for any firmware updates.Connect your vacuum to the Dyson app (if applicable) to ensure everything is functioning as intended.When to Seek Professional HelpIf, after all the troubleshooting, your vacuum remains non-functional, it may be time to consult a professional.Persistent power issues despite a functional power source.Physical damages that can’t be assessed or repaired at home.Always refer to Dyson’s customer service or consult a certified technician for repairs to avoid voiding the warranty.ConclusionUnderstanding the common issues behind why your Dyson vacuum may not be working is key to effective and efficient troubleshooting. The combination of regular maintenance such as cleaning filters, emptying the dirt bin, and checking for blockages will significantly enhance the vacuum’s performance and lifespan. When in doubt, don’t hesitate to reach out for professional help. Your Dyson vacuum is an investment; taking the time to maintain it properly will keep your home cleaner and your appliance functioning better for years to come.What should I check first if my Dyson vacuum won’t turn on?If your Dyson vacuum won’t turn on, the first thing to check is the power source. Ensure that the vacuum is properly plugged into a working outlet. Sometimes, the issue could be as simple as a loose connection or a tripped circuit breaker. If you have a multi-outlet strip, try plugging the vacuum directly into a wall socket to rule out any issues with the power strip.Additionally, inspect the vacuum’s battery if you own a cordless model. Make sure the battery is charged; it may need to be plugged in and charged for several hours before it can operate. If the vacuum still doesn’t turn on after ensuring it’s charged and properly connected, it might require further inspection or professional assistance.Why is my Dyson vacuum making a strange noise?A strange noise can indicate a few issues with your Dyson vacuum. First, check for any blockages in the hose or brush bar. Debris trapped in these areas can cause unusual sounds as the vacuum struggles to operate effectively. To fix this, turn off the vacuum and clear any visible obstructions. It’s also a good idea to clean the brush bar of hair or dirt that could be winding around it.If clearing blockages doesn’t resolve the noise, it could be a sign of wear or damage to internal components such as the motor or bearings. In this case, refer to the user manual for guidance on disassembling the vacuum for inspection. If you’re unsure or if the problem persists, contacting Dyson support or a professional repair service may be necessary.How do I clean the filters in my Dyson vacuum?Cleaning the filters in your Dyson vacuum is a crucial part of maintenance that can help restore its performance. Start by removing the filters from the vacuum. Most Dyson vacuums have washable filters that can be removed easily. Rinse them under cold water until the water runs clear, and avoid using any detergents or chemicals, as these can damage the filter.After rinsing, allow the filters to air dry completely for at least 24 hours before reinserting them into the vacuum. Regular cleaning of the filters is typically recommended every one to three months, depending on usage, to prevent loss of suction and ensure optimal performance.What should I do if my Dyson vacuum has lost suction?If you’ve noticed that your Dyson vacuum has lost suction, begin by checking for blockages in the hose, filters, or brush bar. Debris can easily accumulate in these areas and significantly reduce the vacuum’s ability to pick up dirt and dust. Detach the hose and inspect it for clogs, while also looking at the filters to ensure they are clean and not saturated with dirt.Once you’ve cleared any blockages, check the brush bar for tangles. Hair and fibers can wrap around the bar, impeding its rotation. Clean the brush bar thoroughly and ensure it can spin freely. If these steps don’t restore the suction, there may be an issue with the motor or other internal components, and professional assistance may be needed.Why is my Dyson vacuum overheating?Overheating in your Dyson vacuum can occur for several reasons, typically associated with clogging or mechanical issues. When airflow is restricted due to blockages in the vacuum’s hose, brush bar, or filters, the motor has to work harder, which can lead to overheating. To address this, turn off the vacuum and inspect all potential blockage points. If you find any, remove them, and then allow the vacuum to cool down.Another possibility for overheating is if the vacuum has been used for an extended period without breaks. It’s important to give your vacuum time to cool down, especially after prolonged use on large areas. If the problem persists even after clearing blockages and allowing it to cool, it may be a sign that there’s a more serious issue with the motor or electrical components, necessitating professional evaluation.How can I reset my Dyson vacuum?Resetting your Dyson vacuum can be a simple way to resolve various issues. To reset it, unplug the vacuum from the power source, wait for about 30 seconds, and then plug it back in. For cordless models, removing the battery for a short time can also serve as a reset. Ensure you follow up by checking for any visible blockages or issues that may have triggered the need for a reset in the first place.Some Dyson models may have specific reset buttons, particularly if they are equipped with advanced features. Consult the user manual for your specific model to see if there are additional steps for resetting and troubleshooting. If resetting does not resolve the problem, further investigation or professional help may be required to diagnose underlying issues.What should I do if my Dyson vacuum isn’t picking up pet hair?If your Dyson vacuum struggles to pick up pet hair, begin by examining the brush bar. Pet hair can get tangled around the brush bar, affecting its performance. Turn off the vacuum and carefully remove any hair or debris wrapped around it. Regularly cleaning the brush is essential to maintain optimal suction performance and avoid clogs.Next, check the vacuum’s filters and ensure they are clean and functioning properly. Clogged filters restrict airflow, which can reduce suction power significantly. After clearing the brush bar and cleaning the filters, run a test to see if there is an improvement. If the vacuum continues to struggle with pet hair, you may need to consider accessories designed for pet owners, such as specialized attachments, or inspect further for mechanical issues. If you’re a proud owner of a Dyson vacuum, you know the joy that comes from a powerful, efficient cleaning experience. However, the dread of encountering a malfunction can be equally as strong. When your Dyson vacuum stops working, frustration can set in quickly. But don’t worry; understanding the common issues behind a malfunctioning Dyson can help you get your device back in prime condition. In this comprehensive guide, we will explore various reasons why your Dyson vacuum may not be working and provide effective solutions that can save you time and money.Understanding Your Dyson Vacuum CleanerBefore diving into the common reasons your Dyson may not work, it’s essential to understand the technology behind these highly-regarded cleaning machines. Dyson vacuums utilize advanced cyclone technology that separates dirt and dust from the air. This design provides efficient suction power and eliminates the need for bags. While the technology is robust and reliable, wear and tear or minor issues can eventually cause problems.Common Reasons Your Dyson Vacuum Is Not WorkingWhen your Dyson vacuum refuses to perform, and you’re left wondering, “Why is my Dyson vacuum not working?” it is crucial to consider the signs that lead to dysfunction. Below, we’ll cover some of the most common reasons, solutions, and tips to maintain your device.1. Bag and Dust Canister IssuesEmptying the Dust Canister One of the primary reasons your vacuum might not work effectively is a full or clogged dust canister. Dyson vacuums have clear containers that allow you to see when they need emptying. If the container is more than half full, it can hinder the suction power significantly.**Solution**: Regularly inspect and empty your dust canister after each cleaning session. To do this, simply press the button to release, remove the canister, and empty the contents into your trash bin. Remember to clean any built-up debris inside the canister.Clogged Filters Dyson vacuums come with HEPA filters, which capture microscopic dust and allergens. Over time, these filters can become clogged and inhibit airflow, leading to reduced suction.**Solution**: To maintain optimal performance, clean the filters every 1-2 months. You can rinse them under cold water without any detergents. Allow the filters to dry completely for 24 hours before reinserting them into the vacuum.2. Battery-Related ProblemsBattery Life and Charging Issues For cordless Dyson vacuums, battery performance is critical. If your device is not charging or runs out extremely fast, it may signal a battery issue.**Solution**: First, ensure that the vacuum is seated properly on the charging dock and that the dock is plugged into a functioning power outlet. If there are still issues, you may need to replace the battery. Check for warranty options if your vacuum is still covered.Faulty Connections Sometimes, the issue may not lie with the battery itself but rather with the connections that charge it.**Solution**: Inspect the charging port for any signs of damage or debris that may obstruct the connection. Gently clean the contacts, if necessary, and check the power supply to ensure it’s functioning.3. Brush Bar and Roller ProblemsBlocked Brush Bar Another frequent reason for a vacuum malfunction is a blocked brush bar or roller. Hair, debris, or tangled fibers can get caught in the brush bar, preventing it from spinning effectively.**Solution**: To resolve this, turn off and unplug your vacuum. Use scissors to carefully remove any hair or debris wrapped around the brush bar. After cleaning, reset the brush bar function if applicable.Damaged Brush Rollers If the brush roller is damaged or worn, it may affect how the vacuum picks up dirt.**Solution**: Inspect the brush bar for any visible damage. If it appears worn out, you might need to replace it, which can often be done easily by ordering a replacement part from Dyson or an authorized dealer.4. Overheating ProblemsUnderstanding Overheating Dyson vacuums are designed with protection against overheating. If your unit overheats, it can shut down as a safety measure, usually indicated by a flashing light.**Solution**: When this happens, turn off the vacuum and check for clogs in the airways, brush bar, or filters. Remove any blockages, let the machine cool down for at least 30 minutes, and it should start functioning again.5. Motor or Electrical IssuesMotor Failure Ultimately, if your Dyson vacuum is still unresponsive after troubleshooting, you may be facing motor issues.**Solution**: Inspect for any unusual noises or burning smells that could indicate motor failure. If you suspect this is the case, it may require professional service as it could involve complex electrical repairs.6. Faulty Controls or ButtonsNon-Responsive Buttons Sometimes, the problem may not be with the vacuum itself but with controls, such as buttons that fail to respond correctly.**Solution**: Make sure there are no obstructions or debris lodged around the buttons. If the issue persists, consider consulting the manufacturer for potential repairs.Regular Maintenance Tips for Your Dyson VacuumPreventative measures are the best way to ensure your Dyson vacuum lasts for years to come. Below are essential maintenance tips that can help you avoid common issues.1. Regularly Clean the FiltersAs mentioned above, clean your filters every 1-2 months. Keeping the filters clean helps maintain optimal airflow and suction power.2. Inspect the Brush Bar and HosesRegularly check your brush bar and hoses for blockages. Remove hair or debris promptly to prevent future clogs and to enhance overall performance.3. Avoid OverheatingLimit usage in areas that may trap excessive hair or dust. Take breaks during operations to allow your vacuum to cool down.4. Store ProperlyKeep your Dyson vacuum in a dry area and avoid extreme temperatures. Ensure the vacuum is charged and ready for use when needed.5. Refer to the ManualYour Dyson vacuum comes with a user manual that contains valuable troubleshooting steps and maintenance recommendations. Always refer to it for specific guidance on your model.Contacting Dyson SupportIf you’ve gone through all the troubleshooting tips and your vacuum is still unresponsive, it may be time to reach out to Dyson’s customer support. Provide them with detailed information about the issue, model number, and any attempts you have made to resolve it.ConclusionExperiencing issues with your Dyson vacuum can be frustrating, but understanding the common problems can lead to effective solutions. Regular maintenance, prompt attention to clogs and other issues, and knowing when to seek professional help will help ensure your Dyson continues serving you well. The high quality and advanced engineering of Dyson vacuums make them a smart investment for any household, and with a little diligence, you can keep yours running optimally for years to come.What should I do if my Dyson vacuum won’t turn on?If your Dyson vacuum won’t turn on, first check to ensure it’s fully charged (for cordless models) or properly plugged in (for corded versions). Inspect the power cord for any visible damage and make sure the outlet is functioning. You can test the outlet by plugging in another device to see if it receives power.If the vacuum still doesn’t turn on after these checks, consider performing a soft reset. For most Dyson models, this involves removing the battery (if applicable), waiting for a minute, and then reattaching it. If the problem persists, there may be an internal component issue that requires professional assistance.Why is my Dyson vacuum making a strange noise?Strange noises from your Dyson vacuum can indicate a problem, such as a blockage or a damaged part. Start by inspecting the vacuum for obstructions in the hose, brush bar, and filters. Hair, dirt, or other debris can accumulate and affect performance, leading to unusual sounds.If you find no blockages, check the brush bar for any tangled hair or string, as this can cause additional stress on the motor, resulting in strange noises. If you still hear unusual sounds after removing blockages, the motor or another internal component may be faulty, and it would be best to consult the manufacturer or a repair technician.How can I fix a Dyson vacuum with low suction power?If your Dyson vacuum is experiencing low suction power, start by checking the filters. A dirty or clogged filter can severely impact performance and should be cleaned or replaced according to the manufacturer’s suggestions. Be sure to wash the filters with cold water and allow them to dry completely before reinserting.Another common cause of low suction is a blockage in the hose or brush head. Inspect these areas for any obstructions, as they can restrict airflow. If necessary, remove the hose and use a long object like a broomstick to dislodge any clogs. If suction remains low after these steps, there may be a more significant issue requiring professional evaluation.What does it mean if my Dyson vacuum is flashing a warning light?A flashing warning light on your Dyson vacuum often indicates a problem with the motor or the battery. Check the user manual corresponding to your model for specific lights and their meanings, as different models may exhibit different patterns or colors for various warnings.Commonly, a flashing red light may suggest the vacuum is overheating, which can happen if it’s blocked or if the filters are dirty. Allow the vacuum to cool down, clean the filters, and remove any blockages before restarting the unit. If the warning light continues to flash, it may require professional servicing to diagnose internal issues.Why does my Dyson vacuum smell bad?If your Dyson vacuum is emitting an unpleasant smell, it may be due to a buildup of dirt, debris, or pet hair that is trapped in the vacuum. Start by checking and cleaning the bin, filters, and brush bar. Regular maintenance can help prevent odors caused by accumulated debris.Another reason for a bad smell could be a burning odor, often an indication that the brush bar is jammed and the motor is overheating. Inspect and clear any tangled hair or object in the brush area. If the smell continues to persist after cleaning, there may be an issue with the motor that could need professional repairs.How often should I clean the filters on my Dyson vacuum?Cleaning the filters on your Dyson vacuum is crucial for maintaining optimal performance. Generally, it is recommended to wash the filters every 1-3 months, depending on usage. Regular cleaning helps remove trapped dust and debris that can affect suction power.To clean the filters, remove them from the vacuum and rinse them under cold water until the water runs clear. Avoid using any detergents, as these can damage the filter fabric. After washing, let the filters air dry completely for at least 24 hours before reinserting them into the vacuum.What do I do if the brush bar isn’t spinning?If the brush bar on your Dyson vacuum isn’t spinning, it could be due to a blockage or an issue with the motor. First, check for any tangles, hair, or debris that may be obstructing the brush. Remove any obstructions from the brush bar to ensure it can turn freely.If the brush bar is clear but still not spinning, it may be a problem with the drive m

will be more polished than ever.See What's NewExplore how consumers want to see climate stories told today, and what that means for your visuals.Download Our Latest VisualGPS ReportData-backed trends. Generative AI demos. Answers to your usage rights questions. Our original video podcast covers it all—now on demand.Watch NowEnjoy sharper detail, more accurate color, lifelike lighting, believable backgrounds, and more with our new model update. Your generated images will be more polished than ever.See What's NewExplore how consumers want to see climate stories told today, and what that means for your visuals.Download Our Latest VisualGPS ReportData-backed trends. Generative AI demos. Answers to your usage rights questions. Our original video podcast covers it all—now on demand.Watch Now Watches The Red Baron won't know what hit him. Watches Rado joins the downsizing movement by releasing the first regular production Captain Cook 39mm, emphasizing the move with two gorgeous dials. Style Is Samba summer finally over? Style What's arguably the best-looking iteration of the GR2 backpack is suddenly below $300, and we're not sure if it'll ever be re-released. Tech Some of the most exciting upcoming Apple Watch features will only be supported on the latest models. Dyson solves real-world problems and creates better products through the application of engineering, science, design and creativity. It is a family-owned, global technology company, founded by Sir James Dyson who remains at the helm alongside his son Jake. Since inventing the first cyclonic bagless vacuum cleaner, the DC01, Dyson has consistently invested in research and development to improve its products and technologies radically. Dyson offers products across a growing range of areas: floorcare, air purification, robotics, haircare including formulations, lighting, hand drying, and most recently audio. Dyson continues to expand into new areas. Today, Dyson sells products in more than 80 markets, has 450 Dyson stores worldwide and is available in all major technology and beauty retailers. Dyson has global headquarters in Singapore and major technology campuses in Singapore, the UK, Malaysia, and the Philippines. Its global team of engineers, scientists and software developers are focused on developing technology-enabled products which work better and which people love to use. Key areas of focus have included high-speed electric digital motors, sensing and vision systems, robotics, machine learning and aerodynamics. Beyond products, to encourage an inventive future, Dyson is also inspiring the next generation of engineers and inventors through the Dyson Institute of Engineering and Technology, the James Dyson Foundation and the James Dyson Award. The Dyson family applies its problem-solving approach in other fields, and established Dyson Farming in 2012. It is one of the largest farming businesses in the UK, extending to 36,000 acres across Lincolnshire, Oxfordshire, Gloucestershire and Somerset. It is a family-owned enterprise unlike any other, focussed on long-term investment in British farming and the countryside to grow tasty and nutritious food. Primary 3 Sentosa Gateway Singapore, 098544, SG Get directions 2 Science Park Dr Singapore Science Park 1, Ascent, #01-08, #03-13/26 The Ascent Tower B Singapore, Singapore 118222, SG Get directions Tetbury Hill Malmesbury, Wiltshire SN16 0RG, GB Get directions 1330 W Fulton Market Floor 5 Chicago, Illinois 60607, US Get directions 300 Barangaroo Avenue Suite 2, Level 22, Tower 3, International Towers Barangaroo, NSW 2000, AU Get directions Rothschildplatz 3 6OG, Top A Vienna, A-1020, AT Get directions 312 Adelaide St W Toronto, Ontario M5V 1R2, CA Get directions Guanghua Road Room 401, 4Fm No. 9 Beijing, 100020, CN Get directions 838 South Huang Pi Nan Road 12F - 15F China Overseas International Centre Building A Shanghai, Huangpu District 200025, CN Get directions Yuehai Street Room F01, 10F, Block B, Aerospace Science and Technology Square, No.1288, Haide 3rd Road Shenzhen, Guangdong 518054, CN Get directions 9 Vla Pierre Ginier Paris, 75018, FR Get directions Lichtstraße 43e Cologne, North Rhine-Westphalia 50825, DE Get directions 60 Wyndham Street 11/F, The Centrium Hong Kong, HK Get directions 43 Residency Road WeWork Galaxy Level 5 Bengaluru North, Karnataka 560025, IN Get directions Forum Mall, Hosur Road Bangalore, Karnataka 560095, IN Get directions Mechelsesteenweg 180 Fosburys & Sons Antwerp, 2018, BE Get directions Sumitomo Fudosan Fukuoka 1-12-1 Kojimachi Hanzomon Bldg. 7F Tokyo, 102-0083, JP Get directions Plo 208, Jalan Cyber 14 Senai Industrial Estate IV Senai, Johor 81400, MY Get directions Paseo de los Virreyes 45 Plaza Corporativa Puerta de Hierro. C.P. Zapopan Guadalajara, 45116, MX Get directions Banjara Hills Workafella 6-3-252/2, Erramanzil Hyderabad, Telangana 500082, IN Get directions De Ruijterkade 139 Amsterdam, 1011AC, NL Get directions Al. Jana Pawła II 22 Warsaw, 00-133, PL Get directions Usacheva 35A Moscow, Moscow Oblast 119048, RU Get directions Paseo de Recoletos 37 Floor 3 Madrid, 28004, ES Get directions Kalanderplatz 5 Stadtkreis 3 Wiedikon, Zurich 8045, CH Get directions Ataşehir içerenköy mah. umut sokak quick tower no:10-12 kat:9 ataşehir Istanbul, 34746, TR Get directions Cluster O 3201 Reef Tower JLT Dubai, 5003350, AE Get directions 32-34 Gresse Street London, England W1T 1QU, GB Get directions 38 North Row London, W1K 6DH, GB Get directions Nungambakkam High Road #10 Uthamar Gandhi Salai, Workafella Business Center Chennai, Tamil Nadu 600034, IN Get directions DLF Cyber City, Phase III, Sector 24 WeWork Forum Gurugram, Haryana 122002, IN Get directions Veera Desai Industrial Estate, near Fun Republic 14th Floor, Lotus Business Park Mumbai, Andheri West, Maharashtra 400053, IN Get directions Central Park, Carmanhall and Leopardstown Unit 2, Building 4 Vantage Dublin, 18D18 EW29, IE Get directions Piazza Gae Aulenti Milan, Lombardy 20154, IT Get directions Blvd. Miguel de Cervantes Saavedra 233-Piso 1 Mexico City, Granada 11520, MX Get directions Amsterdam, North Holland 1011 AC, NL Get directions 6 / 99 Carbine Road, Mt Wellington Auckland, 1060, NZ Get directions 2 River Valley Road Lot C3 -13 Punta, Calamba, Laguna 4027, PH Get directions Block 45 Alabang Zapote Road cor. North Bridgeway, Alabang Filinvest Corporate Center Level 16 Aeon Center Lot 2A and 3 Muntinlupa, 1781, PH Get directions Aleksandra Lubomirskiego 24 Unity Centre Krakow, 31-509, PL Get directions Av. António Augusto de Aguiar 122C Lisboa, 1050-046, PT Get directions 30 Pioneer Crescent West Park Bizcentral Singapore, 628555, SG Get directions Kungsträdgårdsgatan 10 Stockholm, 111 47, SE Get directions One Cathedral Square Bristol, BS1 5TE, GB Get directions Hullavington Airfield Hullavington, SN14 6GU, GB Get directions 27 Margaret Street London, W1W 8RY, GB Get directions Tetbury Hill Malmesbury, England SN16 0RP, GB Get directions If you're looking for a luxuriously relaxing yet welcoming holiday, this four-star beachside resort is the only choice Your Dyson vacuum has lost suction? They aren't supposed to lose suction according to Dyson. So what do you do? Here's a bunch of helpful solutions to the problem you have. So, it’s that time of the week when you do your routine vacuuming to get rid of dust and pet fur from your living space. However, your Dyson vacuum cleaner has stopped working, and you can’t complete the job. A Dyson vacuum will stop working if it has power issues, the filter has problems, or the motorhead has malfunctioned. A damaged vacuum belt and blockages in the airway or other parts may also cause your Dyson unit to stop working. Also, if it’s in the upright position, it normally won’t turn on. This complete troubleshooting guide will cover the common causes why your Dyson vacuum has stopped working. Read on as we diagnose these problems and offer you solutions to resolve them. Dyson Vacuum Won’t Turn On When Upright If your Dyson vacuum won’t turn on when upright, you shouldn’t panic as that’s how they normally are. Dyson vacuums are designed to lock into an upright position when you’re not using them. As explained by the Dyson Operating Manual for DC25, the upright position disengages the brush bar. The brush bar won’t rotate as long as the vacuum is in that position. To use the vacuum, press the button next to the cleaning head with your foot. This unlocks the handle, and you can recline the vacuum. The manual explains that the upright position is also the correct position when using the vacuum tools. Dyson Vacuum Won’t Turn On After Cleaning Filter If your Dyson vacuum won’t turn on after cleaning the filter, it could be due to several reasons. You installed the filter incorrectly or replaced it while still wet. The motorhead may have also been damaged by water from a wet filter, or there are blockages in other parts of the vacuum. Dyson Vacuum Filter Is Incorrectly Installed Cleaning your Dyson vacuum filter, or replacing a damaged one with a new one, should optimize its performance. But that won’t happen if you fix it incorrectly after diligently cleaning the filter or paying a good buck for a new one. When removing your Dyson filter, you have to turn it anticlockwise and pull it out. To fix it back, you should twist it clockwise until it clicks. If you don’t do this, your vacuum won’t turn on. It’s important to note that your Dyson vacuum may detect an incorrectly fitted filter if dirt stands between the filter and its fitting on the vacuum. How To Diagnose and Fix an Incorrectly Fitted Dyson Vacuum Filter If your Dyson vacuum has the filter wrongly fitted, the blue light will be flashing. This may vary with different models, so check your user manual for the correct interpretation of the flashing lights. To fix it, simply remove the filter and refit it back. While you’re at it, ensure that there’s no dirt sitting on the filter’s fitting space. You can check the sticker at the back of the filter for instructions. Dyson Vacuum Filter Is Fitted While Still Wet You should never refit your Dyson vacuum filter without allowing it to dry completely after washing. Fitting a wet filter risks blockage to the airway because the water doesn’t allow the air to pass. As a result, there’s poor air supply to the entire vacuum, and the appliance shuts itself as auto protection. How To Diagnose and Fix Your Vacuum Filter That’s Fitted Wet It’s easy to tell that your vacuum filter is still wet if you feel some wetness when you hold it to fit it back in its place. You can also shake the filter a little and notice if any water droplets fall out of the filter. Dyson recommends that you should leave your vacuum filter in a warm place for 24 hours to dry completely. Also, you should NEVER dry a filter under direct sunlight, using a naked flame or a tumble drier, or by placing it in a microwave. So, if you had refitted a wet filter into your Dyson vacuum, remove the wet filter and leave it out for 24 hours so it can dry completely. The vacuum also needs to dry because some of the water may have gone into adjacent parts. Dyson Vacuum Has a Malfunctioned Motor Head If you’ve just washed your Dyson vacuum filter and accidentally fitted it back wet, the unwanted water could end up in the electrical part of the motor. This could cause a short circuit and damage the motor, making the vacuum shut off. How To Diagnose and Replace Your Damaged Dyson Vacuum Motor If, before shutting off abruptly due to a wet filter, your Dyson vacuum has a strong burning smell, then it’s likely that the motor has malfunctioned and needs to be replaced. Follow these steps to replace your Dyson vacuum motor: Ensure your safety by turning off the power switch and unplugging. Disassemble the wand and motorhead. Remove the bin. Remove the battery. Remove the cyclone from the motor. Attach the new motor to the cyclone. Replace the battery. Refit the bin. Reattach the wand and motorhead. Your Dyson vacuum should resume working. This video from YouTube is a detailed visual demonstration of how to replace the motor on a Dyson vacuum: The Dyson Vacuum Has Blockages Elsewhere If you’ve just cleaned your Dyson vacuum filter and have allowed it to dry well before refitting it, but your vacuum still won’t turn on, the vacuum may have blockages in other parts: the wand, brush bar, or the air inlet. This is especially true if your vacuum pulsates when you try to turn it on. How To Diagnose and Fix Dyson Vacuum Blockages Assess the vacuum parts that are susceptible to blockages such as the: Hose Wand and wand handle Airway Cleaner head Brush bar Air inlet Bin inlet Notice any signs of fluff and dirt buildup, pieces of objects, or hairballs in these spaces. To fix possible Dyson vacuum blockages, follow these steps: Turn off your Dyson vacuum and unplug the cable from the wall outlet. Disassemble the vacuum.Assess each of the parts for clogging debris. Dyson Vacuum Shuts Off After a Few Minutes If your Dyson vacuum shuts off after a few minutes, it could be that the vacuum has power issues. Other possible reasons include the vacuum fuse being dead, the vacuum belt being damaged, or there are blockages in the vacuum that make it work harder and overheat. Dyson Vacuum Has Power Issues A Dyson vacuum that has power issues will either not turn on at all or shut off after a few minutes. Power issues may result from one of these causes: A bad wall outlet. A tripped circuit breaker due to a power surge while the vacuum was running. How To Diagnose and Fix Dyson Vacuum Power Issues Perform one of these actions to resolve Dyson power issues: Test the wall outlet for faults by trying to power another appliance. If the appliance runs without any issues and doesn’t stop, then the vacuum has a problem. If the other appliance turns off after a few minutes, the wall outlet has a problem. If the wall socket is working, check if the circuit breaker has tripped. A tripped circuit breaker will have the switch turned downwards. Depending on your diagnosis, perform one of the following: Call in a professional electrician to repair a faulty wall outlet. If the circuit breaker is tripped, pull the switch back up and test the vacuum to see if it resumes working. If the circuit breaker switch is hard to turn, never try to force it. You should call in a professional electrician instead. Note: If you have a cordless Dyson vacuum model, power issues could be caused by a dead battery or a damaged battery casing. Recharge the battery or replace the battery casing as the case requires. Dyson Vacuum Has a Dead Fuse If there are no issues with power at the wall outlet or the circuit breaker, then your Dyson vacuum fuse could be blown. A blown Dyson vacuum fuse can be caused by: Power fluctuations An overheating vacuum A vacuum turning off abruptly How To Diagnose and Fix a Dead Dyson Vacuum Fuse A blown fuse will have some dark color inside the glass or a broken or melted filament. Using the wrong type of fuse can also cause it to blow. To fix issues with a blown Dyson vacuum fuse: Ensure you’re using the correct fuse. The standard fuse in Dyson vacuums is a brown 13A fuse. Check for secondary causes of a blown Dyson vacuum fuse like dirty filters, electricity issues in the home, or damaged vacuum seals and parts. Dyson Vacuum Has a Damaged Belt Vacuum belts have the function of spinning the brush roller and turning the vacuum wheels in some models. If your Dyson vacuum belt breaks or has some cracks, the motor will malfunction, leading to overheating. A blown or tripped fuse, or abrupt power loss to the vacuum, are all possible consequences of a broken vacuum belt. How To Diagnose and Replace Your Damaged Dyson Vacuum Belt The first possible signs of a damaged Dyson vacuum belt include a vacuum that keeps tripping or blowing or there’s an abrupt power loss to the unit. For a more precise diagnosis, open the brush roll area of the vacuum and notice if the belt is hanging loosely on the brush roller. A broken vacuum belt needs replacement. To replace a damaged Dyson vacuum belt, follow these steps: Open the brush roll area of your vacuum by removing the screws holding the bottom plate. This will reveal the brush roller and the belt. Remove the brush roller and belt. Be sure to check how they’re fixed on the vacuum, so you have no trouble placing them back.Remove the broken belt from around the roller. You may not need to remove the other end of the belt from the motor shaft if the belt is broken. However, if still held by the motor shaft, pull that end out too. Install the new belt on the brush roller and motor shaft. Ensure you’ve ordered and purchased the right belt for your Dyson model. Check your User’s Manual or call Dyson support if you’re not sure. Place back the bottom plate and tighten the screws to fasten it. You can now test your Dyson vacuum and get back to your vacuuming task. This video from Dyson is a visual demonstration of how to replace a damaged Dyson vacuum belt: The vacuum belt replacement steps are for DC07 and DC14, which generally apply to other models. If you’re not confident you can complete this process with ease and without causing further damage, call in a professional to do the job. Dyson Vacuum Has Blockages A Dyson vacuum with blockages creates the risk of overheating due to reduced airflow. Blockages can happen in the hose or at the brush bar and attachments. If your Dyson vacuum has a blockage, it’ll be working harder than usual to get the required air supply, and the resulting overheating can cause it to shut down. How To Diagnose and Fix Your Dyson Vacuum That Has Blockages Check your vacuum hose, brush bar, and attachment for blocking objects that could be hairballs, pieces of children’s toys, or accumulated dust and fluff. To remove blockages from your Dyson vacuum, follow these steps: Turn off your Dyson vacuum and unplug the cable from the wall outlet. Disassemble the vacuum and assess each of the parts for clogging debris. These are the parts you should disassemble and assess for blockage: Wand and wand handle Cleaner head Brush bar Airway above the cleaner head Neck of the cleaner head Bin inlet Air inlet Extension tube Watch how to check your Dyson vacuum for blockages and follow the demonstration to disassemble and clear the blockages. Note that there could be slight variations depending on your vacuum model. Final Thoughts A Dyson vacuum that’s not working when you need your vacuuming job done can be extremely frustrating. Common problems include Dyson vacuum not turning on when upright, not turning on after cleaning the filter, and keeps shutting off after a few minutes. Knowing how to troubleshoot issues affecting your vacuum can save your day. We hope this article has given you the practical tips you need to do precisely that. Recommended Reading: Dyson Vacuum Making Loud Noise? 4 Possible Causes and Fixes Declutter your home once and for all (Even if you have no time and don't know where to begin)! Learn More. Have you ever been frustrated by your Dyson vacuum when it suddenly stops performing its magic on your floors? You’re not alone.Dyson vacuums are known for their powerful suction and sleek design, but like any appliance, they can run into issues. Imagine confidently tackling those pesky problems without calling in costly professionals or feeling overwhelmed. This guide is here to empower you.With straightforward troubleshooting tips, you’ll get your Dyson back to its best, ensuring your home stays spotless. Dive in, and let’s turn your vacuum woes into wins!Dyson vacuums are celebrated for their innovation and efficiency, yet like any appliance, they can run into problems. Knowing the common issues with Dyson vacuums can save you time and frustration. Whether you own a sleek cordless model or a robust upright, understanding these issues can make your cleaning routine smoother.Loss Of SuctionOne frequent problem is loss of suction. You might notice your Dyson isn’t picking up dirt as it used to. This can often be traced back to a clogged filter or hose. Make it a habit to clean these parts regularly. A simple rinse under water might be all it takes to restore your vacuum’s power.Have you ever wondered if you’re vacuuming correctly? Sometimes, adjusting your vacuuming technique can improve suction. Ensure you’re not forcing the vacuum over debris, which can block airflow. Let the machine glide, and you might find it picks up more than you expected.Unusual NoisesUnusual noises can be startling and often signal an issue. If your Dyson starts to sound like a jet engine, it might be due to a blockage. Check for any obstructions in the brush bar or hose. A small toy or piece of fabric might be the culprit.Regular maintenance can prevent these noises. Have you checked the brush bar lately? Removing hair and threads can keep it running smoothly. A quiet vacuum means a happy home, and a little attention can go a long way.Battery ProblemsBattery life is crucial for cordless models. If your Dyson isn’t holding a charge, it might be time to replace the battery. Before you rush to buy a new one, make sure it’s properly connected. Sometimes a simple reconnection solves the issue.Curious about extending your battery’s life? Avoid using your vacuum at full power unless necessary. This preserves battery life and ensures your Dyson is ready for bigger cleaning tasks. Do you really need turbo mode for crumbs on the carpet?Filter MaintenanceFilters are often overlooked but are vital for optimal performance. A dirty filter can lead to reduced suction and efficiency. Regularly washing and drying your filters can prevent this. You’d be surprised how a clean filter can refresh your Dyson.Ever thought about setting a reminder to clean your filters? It can be as simple as marking your calendar monthly. A clean filter not only boosts performance but also prolongs the life of your vacuum. Isn’t it worth a few minutes of your time?By addressing these common issues, you can keep your Dyson vacuum running smoothly. Regular maintenance and attention to detail can prevent minor problems from becoming major headaches. What steps will you take to ensure your Dyson remains a reliable cleaning partner?Dyson vacuums are known for their reliability and innovative design. However, even the best machines can encounter power problems. These issues can be frustrating, especially when you’re trying to keep your home clean. Understanding the root of these problems can save you time and possibly some money. Let’s dive into two common issues: when your vacuum won’t turn on and intermittent power loss.Vacuum Won’t Turn OnImagine this: you’re ready to tackle the mess in your living room, but your Dyson vacuum simply refuses to turn on. First, ensure the power cord is firmly plugged into a functioning outlet. It might sound simple, but sometimes a loose plug is all that’s needed to halt your cleaning plans.Next, check the vacuum’s fuse. Over time, fuses can blow and prevent your vacuum from starting. Replacing a fuse is usually straightforward and can often be done at home with a few basic tools.If you’ve checked the cord and fuse, inspect the battery if you have a cordless model. Sometimes, the battery might need a charge or even replacement. Have you ever overlooked charging your devices, only to find them dead when you need them most? It’s easy to do!Intermittent Power LossPower loss during vacuuming can be incredibly disruptive. You might be in the middle of cleaning a carpet when suddenly the vacuum stops. One common cause is a loose connection, either in the plug or inside the vacuum itself.Check all connections. Ensure they’re tight and secure. A simple adjustment can often restore consistent power. If the vacuum continues to lose power, examine the power cord for signs of damage.Have you ever had a phone charger that only works at certain angles? Similar wear can happen to vacuum cords. If the cord is frayed or damaged, it might be time for a replacement. Regularly inspecting your vacuum for such issues can prevent unexpected power losses.Are these power issues something you’ve faced with your Dyson? Sometimes, tackling these problems head-on can seem daunting, but with a bit of guidance, you might find it’s simpler than you think.Dyson vacuums are known for their strong suction power. But sometimes, you may notice a decrease in suction. This can be frustrating during cleaning. Several reasons can cause this issue. Knowing these can help restore the vacuum’s efficiency.Filters play a crucial role in maintaining suction. Dust and dirt can block them over time. Regularly cleaning or replacing filters is essential. Remove the filter and rinse it under cold water. Let it dry completely before reattaching. Following these steps ensures your vacuum performs well.Debris often gets stuck in the hose or wand. This blockage can reduce suction significantly. Check these parts for any obstructions. Use a long object to dislodge debris gently. Make sure the hose and wand are clear before resuming cleaning.Experiencing brush bar malfunctions in Dyson vacuums can disrupt cleaning efficiency. Common issues include tangled hair or debris blocking movement. Regular maintenance, like checking for obstructions and cleaning the brush bar, can help restore performance.When your Dyson vacuum’s brush bar malfunctions, it can feel like you’re stuck in a cleaning nightmare. The brush bar is essential for picking up dirt and debris from carpets and hard floors. If it’s not working, you’re left with a vacuum that doesn’t live up to its powerful reputation. Before you decide it’s time for a repair shop visit, consider these common issues and how you might resolve them on your own.A brush bar that refuses to spin can be frustrating. First, ensure the vacuum is powered on and the brush bar switch is activated. It might seem obvious, but sometimes the simplest checks can solve the problem.Next, inspect for any blockages. Hair, strings, or debris can get tangled around the bar, preventing it from moving. Safely unplug your vacuum before attempting to remove any obstructions. Use scissors to carefully cut away any tangled materials.If the brush bar still doesn’t spin, the problem might be with the motor or the belt. Check if the belt is loose or broken. If it is, replacing it could get your brush bar back in action. Dyson customer service can provide guidance on obtaining the correct parts if needed.Hearing strange noises when the brush bar is active? These sounds can be alarming. Often, unusual noises signal that something is caught in the brush bar mechanism.Start by turning off and unplugging the vacuum. Look closely for any visible obstructions or damage. Even small items like paper clips or pebbles can cause noise and affect performance.If you find nothing unusual, consider the condition of the brush bar bearings. Worn-out bearings can lead to grinding noises and should be replaced. Does your vacuum sound like a coffee grinder? It’s time to inspect those bearings!Unexpected noises might also come from a misaligned brush bar. Realigning it can sometimes solve the problem. Ensure that the brush bar is seated correctly in its housing to avoid any misalignment issues.Have you ever fixed a brush bar issue on your own? It’s empowering to solve a problem without professional help. Share your experiences and tips in the comments below—your insight might help another reader facing the same issue.Dyson vacuums are trusted for their powerful performance. Yet, like any appliance, they can face problems. One common issue is overheating. This can disrupt your cleaning routine. Understanding why it happens is key to fixing it. Regular maintenance can prevent overheating. Let’s explore how to tackle this problem effectively.Automatic Shut OffWhen a Dyson vacuum overheats, it often shuts off automatically. This feature protects the motor from damage. It’s a sign the vacuum needs attention. Check for clogs in the hose or filters. Blockages can restrict airflow, causing the motor to heat up. Clearing these can solve the problem.Cooling Down The MotorIf your vacuum shuts off, allow it to cool. This is crucial for safety. Unplug the device and wait at least 30 minutes. Use this time to inspect the vacuum. Check for obstructions in the airways. Proper airflow helps keep the motor cool. Clean filters regularly to ensure smooth operation.Whether you’re tackling stubborn pet hair or crumbs from breakfast, Dyson vacuums are a powerhouse for maintaining a clean home. However, nothing disrupts your cleaning spree like battery and charging concerns. Addressing these issues promptly ensures your Dyson remains reliable and efficient. Let’s dive into some common problems and solutions regarding the battery and charging of your Dyson vacuum.Battery Not Holding ChargeImagine gearing up to tackle your living room only to discover your Dyson’s battery is running low fast. This issue can be frustrating but often fixable. Begin by checking the battery age. Most Dyson batteries last around three to five years. Is yours older? It might be time for a replacement.Another tip is to avoid storing your vacuum in extreme temperatures. Heat and cold can affect battery life significantly. Try keeping it in a moderate, dry environment for optimal performance.Additionally, ensure the battery is securely connected to the vacuum. Loose connections can cause charging interruptions. A simple check and adjustment can make a world of difference.Charging ErrorsCharging errors can be a headache, especially when you’re in a rush. Start by examining the charging cable for any visible damage. Frayed wires or bent plugs can prevent your Dyson from charging properly.Check the power outlet. Sometimes, the issue isn’t with the vacuum but with the outlet itself. Plug another device into the same outlet to test its functionality.Are you using the correct charger? Using a charger not specifically designed for your Dyson model can result in charging errors. Ensure compatibility to avoid this pitfall.Have you ever wondered how small changes can impact charging efficiency? Ensure that your Dyson is clean, especially the connectors. Dust and debris can hinder effective charging. A quick wipe can restore connectivity.As you troubleshoot, don’t forget to give your Dyson some love. Regularly cleaning and maintaining your vacuum can prolong its life and efficiency. Have you faced any of these battery or charging issues before? Share your experience and solutions in the comments below!Credit: youtube.comMaintaining your Dyson vacuum filter is crucial for optimal performance. A clean filter ensures your vacuum operates efficiently. Dust and allergens can clog the filter. This reduces suction power. Regular maintenance can extend the life of your vacuum. It also ensures a healthy living environment. Let’s explore how to clean and replace the filter.Cleaning The FilterCleaning the Dyson filter is simple. First, unplug the vacuum. Locate the filter, usually near the bin. Remove the filter gently. Rinse the filter under cold water. Avoid using detergents or soaps. Shake off excess water. Let the filter air dry for 24 hours. Ensure it’s completely dry before reinserting. Regular cleaning prevents blockages.Replacing The FilterReplacement is necessary if cleaning doesn’t improve performance. Check your user manual for filter type. Purchase the correct filter for your model. Remove the old filter carefully. Insert the new filter securely. Regular replacement keeps your vacuum efficient. It also enhances air quality in your home.Dyson vacuums are known for their efficiency and sleek design. Yet, sometimes they make unusual noises that can be concerning. Understanding these sounds can help in troubleshooting and maintaining your vacuum.Rattling SoundsRattling sounds often indicate loose parts. Check the vacuum head and wand. Ensure all attachments are securely fastened. Inspect the brush bar for debris. Small objects can get trapped, causing a rattling noise. Clear any obstructions carefully.Whistling NoisesWhistling noises usually point to airflow issues. Inspect the hose for holes or blockages. A damaged hose can disrupt airflow, causing a whistle. Examine the filters. Dirty filters can restrict airflow, leading to unusual sounds. Clean or replace them as needed.Dyson vacuum troubleshooting involves using specific tools and resources to resolve common issues. Guides and online forums offer solutions for blockages, power loss, or strange noises. With clear instructions, fixing minor problems becomes straightforward, ensuring your vacuum functions efficiently.Troubleshooting a Dyson vacuum can be straightforward if you have the right tools and resources. Whether it’s a minor hiccup or a more complex issue, knowing where to turn for help can save you time and frustration. Here, we’ll explore some effective resources that can guide you through your vacuum’s troubleshooting journey.Using The User ManualThe user manual is your vacuum’s best friend. It’s often overlooked, but it’s packed with valuable information specifically tailored to your Dyson model. Have you ever flipped through those pages?The manual provides step-by-step instructions for resolving common issues. From clogged hoses to filter maintenance, everything you need is right there. Make sure you keep the manual handy for quick reference when unexpected problems arise.Online Support And ForumsOnline support is a treasure trove of information. Dyson’s official website offers extensive help with troubleshooting guides, FAQs, and video tutorials. Have you checked their resources lately?Forums can also be incredibly helpful. Users share personal experiences and solutions that might just resolve your issue. Reading about someone else’s troubleshooting journey can offer new insights and save you a service call.By tapping into these tools and resources, you can quickly get your Dyson vacuum back in action. Whether it’s diving into your user manual or exploring online communities, the key is to stay informed and proactive. So, what’s your go-to troubleshooting strategy?Dyson vacuums often face issues like loss of suction due to blockages or filters needing replacement. Battery life can diminish over time, affecting performance. Regular maintenance, such as cleaning filters and checking for clogs, can help alleviate these problems and ensure optimal functioning of your Dyson vacuum.Your Dyson vacuum pulsates due to a clogged filter or blockage. Check and clean filters and remove obstructions. Ensure the bin is emptied and inspect the hose for clogs. Regular maintenance prevents pulsating issues and maintains optimal performance.Dyson vacuums don’t have a reset button. To reset, unplug the vacuum for 10 minutes. Reconnect and test.Turn off and unplug your Dyson. Check for blockages in the hose, wand, and brush bar. Remove any debris. Use a flashlight for better visibility. Reassemble and test for proper suction. Regular maintenance prevents future blockages.Check if the power cord is securely connected. Also, verify that the outlet works by testing it with another device.Troubleshooting your Dyson vacuum doesn’t have to be difficult. Follow the steps outlined to identify and fix common issues. Regular maintenance helps prevent problems. Clean filters and check for blockages often. Use this guide as a handy reference. It ensures your vacuum works efficiently.A well-functioning vacuum keeps your home clean and tidy. Don’t hesitate to revisit these tips. They save time and reduce frustration. Enjoy a cleaner home with a properly maintained Dyson vacuum. Regular care makes a big difference. Keep this guide nearby for peace of mind.Happy cleaning! An awesome team of students from our education program made this wiki. The device makes noises and then suddenly turns off. There may be debris blocking the suction, causing the device to shut off. Check for blockages by disassembling the wand from the roller head and the bin. Check inside and around each component. Be careful of sharp objects and debris. Remove any obstructions. The filter could be clogged and may need cleaning. Remove the filter by pulling out the purple knob labeled "filter" located at the top of the bin. Rinse the filter by running it under water for 2 minutes. When done, gently shake the filter to remove any debris. Gently wring out the filter to remove excess water. Allow 24 hours for the filter to dry. After a minimum of 24 hours, replace the filter back into the bin and continue with normal use. The battery may not be fully charged for normal operation. Check the LED light to determine the battery level. A solid blue light indicates that the machine is in normal operating mode. A flashing blue light indicates that there is no power, and the battery needs to be charged for a minimum of 3.5 hours. A flashing yellow light indicates that there is no power or that the battery is too hot or too cold. A flashing red light requires further assistance from the Dyson Helpline. The device does not stay on long enough to complete the vacuuming task. The battery may not be fully charged for normal operation. Check the LED light to determine the battery level. A solid blue light indicates that the machine is in normal operating mode. A flashing blue light indicates that there is no power, and the battery needs to be charged for a minimum of 3.5 hours. A flashing yellow light indicates that there is no power or that the battery is too hot or too cold.. A flashing red light requires further assistance from the Dyson Helpline. When the device no longer powers on even after charging, it most likely has a damaged battery. The battery is unable to charge and will need to be replaced. A replacement guide can be found here. The bin is no longer clear and is filled with debris. The debris clogging the bin may need to be cleaned carefully and completely. Push the red button on the bin case down, over a garbage can. Press the red button again to release the clear bin from the main body. Remove the bin carefully and clean using only a damp cloth. Do not use any cleaning agents besides a damp cloth to preserve the life of your machine. Make sure the bin is completely dry before replacing. Replace the bin with the bin base door open. Snap the bin into place over the cyclone shroud. Close the bin base door so that it clicks secure. After the bin is cleaned, the cyclone shroud may also need cleaning to ensure normal operation. After removing the bin, use the brush on the combination tool to remove dust and lint from the cyclone shroud. Do not put the cyclone shroud under water. Make sure the bin is completely dry before replacing. Replace the bin with the bin base door open. Snap the bin into place over the cyclone shroud. Close the clear bin base door so that it clicks secure. The vacuum loses suction while in operation, or the suction is weak. There may be larger debris blocking the suction from functioning properly. If there are objects blocking the suction, the device will shut off. Check for blockages by disassembling the wand from the roller head and the bin. Check inside and around each one. Be careful of sharp objects and debris. Remove any obstructions. There may be debris preventing the roller head from operating normally. Disconnect the roller head from the wand. If you are unable to remove debris, you may have to remove the brush bar. Unlock the brush bar by using a coin to turn the dial marked with a padlock into the unlock position. Carefully remove the brush bar and remove the debris. After cleaning, refit the brush bar. Secure it by using a coin to tighten the dial marked with a padlock so that it is once again in the lock position. The roller head no longer rotates when the device is on. There may be debris preventing the roller head from operating normally. Disconnect the roller head from the wand. Unlock the brush bar by using a coin to turn the dial marked with a padlock into the unlock position. Carefully remove the brush bar and remove the debris. If there is a blockage in the flat floor tool, remove debris from the base plate. Unlock the base plate by using a coin to turn the dial marked with a padlock into the unlock position. After cleaning, refit the brush bar. Secure it by using a coin to tighten the dial marked with a padlock so that it is once again in the lock position. Replace the base plate, and secure it by using a coin to tighten the dial marked with a padlock so that it is once again in the lock position. There may be debris preventing the roller head from operating normally. Disconnect the roller head from the wand. Unlock the brush bar by using a coin to turn the dial marked with a padlock into the unlock position. Carefully remove the brush bar from the roller head and clear any debris. Replace the brush bar back into the roller head and secure it by using a coin to tighten the dial marked with a padlock so that it is once again in the lock position. Home / Home / Brand Breakdown From Dyson’s latest and greatest cordless vacuums to its older models, here’s everything you need to know about the biggest name in vacuums. Chase Pellerin Every product is carefully selected by our editors. If you buy from a link, we may earn a commission. Learn more Editor’s note: Dyson’s Cyber Monday sale is going on now, with up to $300 off select products! Check out the savings here, and go here for more deals on cleaning, cookware, furniture and more. There is nothing exciting about vacuuming except for the prospect of not having to vacuum for a while. Of course, there are some vacuums that get the job done faster and more efficiently while providing some added benefits in the process. And Dyson specializes in these vacuums. Don’t know where to start? We don’t blame you, which is precisely why we made this cheat sheet to all the Dyson vacuums you can buy. Cordless Stick Vacuums Dyson V12 Dyson Dyson V12 Detect Slim Available: Detect Slim, Detect Slim Extra, Detect Slim Absolute Max Battery Life: 60 minutes Released: 2022 Lasers make everything feel more futuristic, and Dyson’s latest the V12 Detect Slim has a laser in its cleaning head that reveals dirt invisible to the naked eye, a feature that we found makes it one of the best stick vacuums you can buy. If you’ve ever vacuumed and felt like nothing was happening, the V12 uses a thing called an acoustic piezo sensor. The sensor turns the vibrations of dust being sucked up into electric signals, and it’s measured and relayed through an LCD screen to keep track of how much crap you’ve vacuumed. It is one of the lightest vacuums that Dyson has to offer at only 5.2 pounds, which makes it easy to maneuver around and under furniture. Dyson Dyson V15 Detect Plus Available: Detect, Detect Absolute, V15s Detect Submarine, V15s Detect Submarine Absolute Max Battery Life: 60 minutes Released: 2021 Very similar to the V12, the V15 also employs an acoustic piezo sensor and a laser attachment that reveals hidden dirt and dust as you vacuum. The vacuum’s slim laser head — meant for hard floors — is equipped with a green laser that illuminates particles as small as 10 microns, which is about the diameter of human red blood cells. The second cleaning head that comes with the V15 is the High Torque cleaner head, which works on hard floors as well as rugs and carpets. It’s heavier and larger than the V12, making it better suited for heavy-duty cleaning. There’s also the new V15s Detect Submarine, which utilizes Dyson’s first-ever wet vacuum head — the Dyson Submarine — to get your floors sparkling. Dyson Dyson Dyson Gen5detect Available: Gen5detect, Gen5outsize Max Battery Life: 70 minutes Released: 2023 Dyson’s latest cordless stick vacuum, released in 2023, is also its most powerful — no surprise there. The Gen5detect and larger Gen5outsize boast fifth-generation Hyperdymium motors that spin at 135,000rpm, which Dyson claims is nine times faster than a Formula One engine. That translates to a vacuum with enough suction power to capture viruses down to 0.1 microns and trap them in a fully-sealed whole-machine HEPA filtration system. The Gen5detect/Gen5outsize also bests other Dyson sticks when it comes to battery life, running for up to 70 minutes, and gets a redesigned Fluffy Optic cleaner head with a brighter laser that can spot twice as much dust. Read our full review of the Dyson Gen5detect. Dyson Omni-Glide Dyson Dyson Omni-glide Available: Omni-Glide Max Battery Life: 20 minutes Released: 2021 Dyson’s Omni-glide was the brand’s slimmest and most maneuverable stick vacuum when released a couple years ago. It has a cleaning head that swivels 360 degrees that sucks up dirt forward and backward. It was engineered for hard floors, so don’t get this if your home is covered with mostly rugs and carpeting. The 4-pound vacuum qu